


# PENKO Engineering B.V.

Your Partner for Fully Engineered Factory Solutions



Manual:  
1020 FMD

## IMPORTANT SAFETY INFORMATION

### READ THIS PAGE FIRST!

PENKO Engineering B.V. manufactures and tests its products to meet all applicable national and international standards. It is vital that this instrument is correctly installed, used, and maintained to ensure it continues to operate to its optimum specification.

The following instructions must be adhered to and incorporated into your safety program when installing, using, and maintaining PENKO products. Failure to follow the recommended instructions can affect the system's safety and may increase the risk of serious personal injury, property damage, damage to this instrument and may invalidate the product's warranty.

- Read the instructions fully prior to installing, operating, or servicing the product. If this Instruction Manual is not the correct manual for the PENKO product you are using, call 0031(0)318-525630 for a replacement copy. Keep this Instruction Manual in a safe place for future reference.
- If you do not fully understand these instructions, contact your PENKO representative for clarification.
- Pay careful attention to all warnings, cautions, and instructions marked on and supplied with the product.

- Inform and educate your personnel about the correct installation, operation, and maintenance procedures for this product.
- Install your equipment as specified in the installation instructions of the appropriate Instruction Manual and as per applicable local and national codes. Connect all products to the proper electrical sources.
- To ensure correct performance, use qualified personnel to install, operate, update, program, and maintain the product.
- When replacement parts are required, ensure that qualified technicians use replacement parts specified by PENKO. Unauthorized components and procedures can affect the product's performance and may affect the continued safe operation of your processes. The use of non-specified 'look-alike' substitution parts may result in the risk of fire, electrical hazards, or improper operation.
- Ensure that all equipment doors are closed and protective covers are in place, except when maintenance is being performed by qualified persons, to prevent electrical shock and personal injury.

# 1020 FMD

## **WARNING**

### **ELECTRICAL SHOCK HAZARD**

Installing cable connections and servicing this instrument require access to shock hazard level voltages which can cause death or serious injury.

Disconnect separate or external power sources to relay contacts before commencing any maintenance.

The electrical installation must be carried out in accordance with CE directions and/or any other applicable national or local codes.

Unused cable conduit entries must be securely sealed by non-flammable blanking plates or blind grommets to ensure complete enclosure integrity in compliance with personal safety and environmental protection requirements.

To ensure safety and correct performance this instrument must be connected to a properly grounded, three-wire power source.

Proper relay use and configuration is the responsibility of the user.

Do not operate this instrument without the front cover being secured. Refer any installation, operation or servicing issues to qualified personnel.

[WWW.PENKO.COM](http://WWW.PENKO.COM)

PENKO Engineering B.V. is an ETC Company

Email: [info@PENKO.com](mailto:info@PENKO.com)



## Table of Contents

Introduction.....	6
In the box.....	6
Needed for use .....	6
1 Overview .....	7
2 Connections .....	9
2.1 Power supply .....	9
2.2 Load cell.....	10
2.3 USB.....	11
2.4 Analog output.....	12
2.5 Digital inputs.....	13
2.6 Digital outputs .....	14
2.7 Ethernet.....	15
2.9 CAN Bus .....	16
2.10 Profibus.....	17
2.11 RS232/RS422 .....	18
3 Display and keypad .....	20
4 PC applications.....	24
4.1 PDI Client .....	24
4.2 Pi Mach II .....	25
5 First use.....	26
5.1 Using the configuration software.....	26
5.2 Using the device .....	39
6 Full setup.....	46
6.1 Live.....	47
6.2 System .....	47
6.3 System Setup .....	48
6.3.1 Service .....	48
6.3.2 Indicator .....	48



# 1020 FMD

6.3.3	Communication .....	61
6.3.4	Digital inputs .....	68
6.3.5	Digital outputs.....	68
6.3.6	Analog output.....	71
6.3.7	Passwords.....	73
6.3.8	Screen.....	75
6.3.9	Clock .....	79
6.3.10	Printer.....	80
6.3.11	Factory recall .....	84
6.4	Control .....	85
6.5	Access .....	85
7	Alibi Memory and Event Log.....	86
7.1	Alibi Memory .....	86
7.2	Event Log .....	91
8	Firmware update.....	95
8.1	Ethernet .....	95
8.2	USB.....	96
9	Backup and restore .....	98
9.1	Backup .....	98
9.2	Restore.....	98
9.3	Progress .....	98
10	Standard factory settings .....	100
11	Error codes .....	101
12	Specifications.....	102
	Index.....	104
	Appendix I - Menu structure .....	106
	Appendix II - Communication protocols .....	109

# 1020 FMD

## Introduction

The PENKO 1020 FMD is a compact comprehensive Force Measurement Device.

## In the box

The box contains the following items:

- 1 x 1020 FMD device
- 1 x rubber ring for mounting purpose
- 2 x clip for mounting purpose
- 1 x connector for load cell connection
- 1 x quick start manual

## Needed for use

To use the 1020 FMD the following items are needed:

- Class 2 or Limited Power Source, rate 18 - 32 VDC, 0.4A@24VDC
- Load cell / Torque sensor
- USB A-B cable for configuration with PC software

For easy configuration, two PC applications are available as download.



[www.penko.com/software](http://www.penko.com/software)

### PDI Client

PDI Client is a cross-platform freeware program for easy monitoring and configuration of PENKO devices. PDI Client is compatible with the PENKO FLEX series, FLEX2100 series, 1020 series, SGM700/800 series and RQI/RIA700 series. Only USB communication is supported. The minimum required Java Runtime Environment is version 1.8.0. Installation guide and USB drivers for Windows are included.

DOWNLOAD SOFTWARE

### Pi Mach II

Pi Mach II is a comprehensive freeware program for monitoring and configuration of PENKO devices. Available features are firmware update manager, manage tool for all parameters, oscilloscope functionality to explore filters and programming and visualization tooling for the PENKO FLEX and FLEX2100 series. USB drivers are included in the installer.


DOWNLOAD SOFTWARE



an ETC Company

# 1020 FMD

## 1 Overview



Option 1:



Option 2:



# 1020 FMD

Number	Description
1	TFT display 320 x 240
2	Keypad
3	<b>OPTION:</b> None    Serial + CAN bus    Profibus
4	Ethernet connection
5	USB connection
6	Digital inputs (3)
7	Digital outputs (4)
8	24VDC power supply
9	<b>OPTION:</b> Analog output
10	Load cell connection
11	RS232/RS422 connection
12	CAN bus connection
13	Profibus connection
14	Bus termination for Profibus

# 1020 FMD

## 2 Connections

This chapter describes the connections of the 1020 FMD.



Before connecting the device to a computer using USB, make sure the USB driver is installed.

### 2.1 Power supply





Power the device using a Class 2 or Limited Power Source, rate 18 – 32 VDC, 0.4A@24VDC




# 1020 FMD

## 2.2 Load cell



Property	Description
Wiring	With sense
Type of sense	Passive
Excitation voltage	5 VDC
Sensitivity	0,1 $\mu\text{V}/\text{d}$
Selectable ranges	1 mV/V   1,5 mV/V   2 mV/V   2,5 mV/V   3 mV/V
Input voltage @3mV/V	-16 mV to 16 mV
A/D Conversion speed	1600/s
Max. load cell impedance	1200 $\Omega$
Min. Load cell impedance	43,75 $\Omega$
Max. no. of load cells 350 $\Omega$	8
Max. no. of load cells 1000 $\Omega$	22

## 2.3 USB



Connect the device to a computer using an A-B USB cable. The USB interface is used for communication with PENKO configuration software.

Before connecting the device to a computer using USB, make sure the USB driver is installed. The driver is included in the PENKO configuration PC applications, see chapter PC applications.

Only 1 protocol is supported over USB:


Protocol	Description
Penko TP	PENKO protocol used for configuration software



The USB interface cannot be used for printers, memory sticks etc.

# 1020 FMD


## 2.4 Analog output



The analog output can be used as mA output in the following ranges and react to an indicator value.


Range	Description
RAW	16 bit DAC value
0 - 20 mA	The minimum and maximum output of the analog output
0 - 24 mA	The minimum and maximum output of the analog output
4 - 20 mA	The minimum and maximum output of the analog output
4 - 24 mA	The minimum and maximum output of the analog output

The analog output can also be used as 0 - 10 V output when a 500 ohm resistor is placed over the output and the range is set to 0-20mA.



# 1020 FMD

## 2.5 Digital inputs





The device has 3 digital. The inputs can be switched PNP or NPN with 18 - 28 VDC.

The inputs can be programmed as Hold, Peak Hold, Key Lock etc.

# 1020 FMD

## 2.6 Digital outputs




The device has 4 digital outputs that can be used for an AC and DC power circuit up to 35V/0.5A.

The outputs can be programmed as setpoints with a programmable hysteresis and function like Track, Peak, Valley etc.

# 1020 FMD

## 2.7 Ethernet



The Ethernet connection can be used for communication with Pi Mach II and for the following protocols:


Protocol	Description
BusLink	PENKO Protocol to connect the device to a PENKO FLEX controller
EthernetIP	Protocol to connect to SCADA/PLC
Omron FINS	Protocol to connect to SCADA/PLC
Modbus TCP*	Protocol to connect to SCADA/PLC
Penko TP	PENKO protocol used for configuration software
ASCII**	PENKO protocol for ASCII communication

\* Automatically enabled when both RS232 and RS422 are not set to Modbus

\*\* Port 23 - automatically enabled when both RS232 and RS422 are not set to ASCII


# 1020 FMD

## 2.9 CAN Bus



The CAN Bus can be used for the PENKO BusLink protocol, a protocol to connect the 1020 FMD to a PENKO FLEX controller.


Connection	Description
H	CAN High
RTN	Ground
L	CAN Low
SH	Shield




The CANopen protocol is not available

# 1020 FMD

## 2.10 Profibus



Profibus is available on the option board.



Pin No.	Symbol	Name	Description
1		SHIELD	Shield protective ground
2		RP	Reserved for power
3	B/B	RxD/TxD-P	Receive/Transmit data P
4		CNTR-P	Control P
5	C/C	DGND	Data ground
6		VP	Voltage plus
7		RP	Reserverd for power
8	A/A	RxD/TxD-N	Receive/Transmit data N
9		CNTR-N	Control N

# 1020 FMD

## 2.11 RS232/RS422




RS232 and RS422 are available on the option board and can be used for the following protocols:



Protocol	Description
Printer	PENKO protocol to connect a ASCII/plain-text printer
ASCII	PENKO protocol for ASCII communication
NPV Slave	PENKO Protocol used for follow displays
Modbus-RTU	Protocol to connect to SCADA/PLC
Modbus-ASCII	Protocol to connect to SCADA/PLC

# 1020 FMD

RS232 communication:




RS422 communication with multiple devices:



# 1020 FMD

## 3 Display and keypad

The display contains the following indications:



Number	Description
1	Indicator in stable range [ ] Zero active [ ] Range/Interval active
2	Bar graph indication
3	Digital input active indication (3 inputs)
4	Digital output active indication (4 outputs)
5	Measured value
6	Type of value shown on the display (Tracking, Hold, T.I.R, Peak, Valley) *

### \* Display value


<b>Tracking</b>	Tracking value. The display follows the input signal.
<b>Hold</b>	Hold value. The hold value is stored every time the zero button is pressed in hold mode, and every time the input, programmed as hold, is high.
<b>Peak</b>	Peak hold value. This is the highest measured value.
<b>Valley</b>	Valley hold value. This is the lowest measured value.
<b>T.I.R.</b>	Total Indicated Readout value. The difference between the peak hold and valley hold value.

See next page for examples.




# 1020 FMD

## Hold function




## Peak, Valley and T.I.R. function



# 1020 FMD

The display indications in menu mode:



Number	Description
1	Active buttons for current menu item
2	TAC and CAL code*
3	Menu level

## \* TAC and CAL code

**TAC** stands for Traceable Access Code. A number of settings are only available after entering this code. When these settings are changed, the TAC is incremented with 1.

**CAL** stands for CALibration code. The calibration settings are only available after entering this code. When the calibration settings are changed, the CAL is incremented with 1.

# 1020 FMD

The keys have the following functions:



## **Tracking / Hold**

Toggle between Tracking mode and Hold mode.



## **Peak Hold**

Show Peak Hold mode.



## **Enter / Menu**

Adjust levels. Press > 2 seconds to enter configuration menu. In menu mode, press to confirm setting.



## **Zero**

Press to set tare/zero. Press again to reset tare/zero. In Hold mode, press to set hold value. In Peak/Valley/T.I.R mode, press to clear the stored value.



## **Print / Escape**

Press to cancel or step back one menu item. Press from start screen to print.



## **Up / Increase value**

From start screen, press to show T.I.R. value on the display.



## **Down / Decrease value**

From start screen, press to show valley hold value on the display.



## **Left / Change position of cursor**



## **Right / Change position of cursor**

# 1020 FMD

## 4 PC applications


For easy configuration and monitoring, two PC applications are available as download. PDI Client and Pi Mach II. In the following chapters, Pi Mach II is used to explain the 1020 FMD functionality.



[www.penko.com/software](http://www.penko.com/software)

### 4.1 PDI Client

PDI client is a small cross-platform application that only works with USB communication. It can run on any operating system that runs Java Runtime Environment (JRE). All device properties are shown in a tree structure and can easily be edited.




USB driver and user manual are included in the download



# 1020 FMD

## 4.2 Pi Mach II

Pi Mach II is a comprehensive Windows application that works with USB and Ethernet communication and has more functionality compared to PDI Client. The tree structure configuration of PDI Client is available in this program. Other features are backup and restore, firmware updates and a build in oscilloscope to analyze signals for different filter settings.



USB driver and user manual are included in the download

## 5 First use


For first use, the following settings are important:

- Unit indication
- Decimal point position
- Step size
- Maximum load
- Calibration
- Communication

This chapter describes how to adjust these settings with the configuration software and on the device itself.

### 5.1 Using the configuration software

Make sure Pi Mach II and the USB driver are installed properly according to the Pi Mach II user manual. Open Pi Mach II and open Manage.



These configurations can also be made with the PDI Client software

# 1020 FMD

The left screen shows the device configuration in a tree structure. The right screen shows the properties of the selected item in the left screen. For example the live force information:

The screenshot shows a configuration interface with a tree view on the left and a properties panel on the right. The tree view shows a hierarchy starting with 'PENKO', followed by 'PENKO 1020', and then 'Live' > 'Indicator' > 'Force'. A red arrow points from the 'Force' item in the tree to the properties panel. The properties panel displays the following information:

Class: PENKO.PENKO 1020.Live.Indicator.Force	
Path: 1.1.1.3.1	
Fast Tracking	0 kN
Tracking	0,000 kN
Peak	0,000 kN
Valley	0,000 kN
Hold	0,000 kN
T.I.R.	0,000 kN
Fast Tracking x10	0,000 kN
Tracking x10	0 kN
Peak x10	0,0000 kN

Buttons at the bottom of the properties panel include 'Discover', 'Import Properties (CSV)', and 'Apply'.

In the tree, select **PENKO 1020**. The properties of this tree node are shown in the right screen.

The screenshot shows the configuration interface with 'PENKO 1020' selected in the tree view. The properties panel displays the following information:

Class: PENKO.PENKO 1020	
Path: 1.1	
Name	
	<input type="button" value="Start Quick setup"/>
	<input type="button" value="Enable Full setup"/>

The first use settings are available under **Start Quick setup**

The screenshot shows the configuration interface with the 'Quick Setup' sub-menu expanded under 'PENKO 1020'. The sub-menu items are:

- Step 1, Indicator Parameters
- Step 2, Indicator Setup
- Step 3, Calibrate
- Step 4, Communication
- Done



To confirm a setting press enter or click the Apply button

# 1020 FMD

## Select Step1, Indicator Parameters

Unit	<input type="text" value="kN"/>
Decimal point	<input type="text" value="000.000"/> ▼
Step	<input type="text" value="STEP 1"/> ▼
Maxload	<input type="text" value="10,109"/> kN

### Unit

Set the unit of measurement, for example kN or N. This will be shown everywhere the measured force is displayed or printed.

### Decimal point

Select the position of the decimal point. This setting will be used everywhere the measured force is displayed or printed.

Available options
000000
00000.0
0000.00
000.000
00.0000
0.00000

### Step

Select the step size. This setting defines the scaled parts of the force value. The display value will be rounded to the nearest value with a valid step size. Available options:

Available options
1
2
5
10
20
50
100
200

# 1020 FMD

→ Example:

Measured value is 2005 kN.

Step size	Displayed value
1	2005
2	2006
5	2005
10	2010
20	2000
50	2000
100	2000
200	2000

## Maxload

Set the force the indicator will use as maximum. If the measured force is higher than the maximum load, the display will show =====



More weigher parameters are available in the Full setup

# 1020 FMD

Select **Step2, Indicator setup**

<b>Application</b>	Unknown
--------------------	---------

## Application

A number of predefined configurations with specific filter settings are available. These configurations don't affect the settings made in step 1. They only affect the filter settings.

### Available options

Unknown

Standard indicator

Fast indicator

When setting up an installation, select the appropriate configurations and start fine tuning it with the options available in the Full setup.



Filter settings are explained in the Full setup chapter



an ETC Company

# 1020 FMD

## Select **Step 3, Calibrate**

<b>Live gross</b>	cccccc kN
<b>Live signal</b>	0,3069 mV
<b>Scale empty</b>	0,000 kN
	<input type="button" value="Calibrate scale empty"/>
<b>Enter load on scale</b>	<input type="text" value="10,000"/> kN
	<input type="button" value="Calibrate load on scale"/>

With this step a two-point calibration can be made. The unit indication and decimal point position are a result of the settings in step 1.

### **Live gross**

This shows the gross indicator value. When no calibration is available this will show **cccccc**

### **Live signal**

This shows the voltage generated by the connected load cell or force sensor.

### **Scale empty**

The calibration of the “zero” point.

Make sure the load cell or force sensor is not loaded and is stable.

Click  and the zero point is saved.

### **Enter load on scale**

The calibration of the “gain” point.

Make sure the load cell or force sensor is loaded with the reference weight and is stable.

Set the reference weight.

Click  and the gain point is saved.

The device is now calibrated.



More calibration options are available in the Full setup



an ETC Company

## Select **Step 4, Communication**



Every available communication port has its own settings. The available ports depend on the option board.

## Ethernet

<b>MAC</b>	1E:30:6C:A2:45:5A
<b>Name</b>	<input type="text"/>
<b>Address</b>	<input type="text" value="10 . 1 . 2 . 69"/>
<b>Mask</b>	<input type="text" value="255 . 255 . 255 . 0"/>
<b>Gateway</b>	<input type="text" value="0 . 0 . 0 . 0"/>
<b>DHCP</b>	<input type="text" value="DISABLE"/>

### MAC

This shows the MAC address of the device. This number cannot be changed.

### Name

Domain Name System (DNS). A name can be given to the device to access the device in the Ethernet network by name instead of by IP address.

### Address

Set the IP address of the device. Make sure the IP address is in the IP range of the network.

### Mask

Set the subnet mask of the device.

### Gateway

Set the gateway of the network the device is connected to.

### DHCP

Dynamic Host Configuration Protocol (DHCP). When this function is enabled, the device gets an IP address, subnet mask and gateway address from the network it is connected to.



# 1020 FMD

## Ethernet BusLink

<b>Address</b>	<input type="text" value="0"/>
<b>Sub address</b>	<input type="text" value="0"/>

BusLink is a PENKO protocol to connect the device to a PENKO FLEX series device. The device parameters like indicator values and I/O status become available in the PENKO FLEX. A BusLink network can contain up to 40 PENKO devices (*8 addresses x 5 sub addresses*).

### Address

Set the BusLink address.

Available options
0 = off
1
2
3
4
5
6
7
8

### Sub address

Set the BusLink sub address.

Available options
0 = off
1
2
3
4
5

# 1020 FMD

## RS232 / RS422

<b>Protocol</b>	Printer
<b>Address</b>	0
<b>Stopbits</b>	1
<b>Parity</b>	None
<b>Baudrate</b>	9600
<b>Indicator</b>	0

The available options for RS232 and RS422 are the same and therefore described only once.

### Protocol

Select the protocol for the serial port.

#### Available options

None

Printer

ASCII

NPV Slave

MODBUS-RTU

MODBUS-ASCII

### Address

Set the address of the port for identification in the network.

#### Range

0...255

### Stopbits

Set the number of stop bits needed for the selected protocol.

#### Range

1...2

# 1020 FMD

## Parity

Set the parity needed for the selected protocol.

Available options
None
Odd
Even
Mark
Space

## Baudrate

Set the baud rate needed for the selected protocol.

Available options
1200
2400
4800
9600
19200
38400
57600
115200

## Indicator

This option is only active when ASCII is selected as protocol. The value of the selected indicator will be sent out over the communication port.

Range
1...30

# 1020 FMD

## CAN

<b>Protocol</b>	None ▼
<b>Buslink Address</b>	0
<b>Buslink Subaddress</b>	0
<b>Baudrate</b>	250k ▼

BusLink is a PENKO protocol to connect the device to a PENKO FLEX series device. The device parameters like indicator values and I/O status become available in the PENKO FLEX. A BusLink network can contain up to 40 PENKO devices (*8 addresses x 5 sub addresses*).

### Protocol

Enable or disable the BusLink protocol.

#### Available options

None
Buslink

### Buslink Address

Set the BusLink address.

#### Available options

1
2
3
4
5
6
7
8

# 1020 FMD

## Buslink Subaddress

Set the BusLink sub address.

Available options
1
2
3
4
5

## Baudrate

Set the baud rate equal to the baud rate of the connected PENKO FLEX.

Available options
100k
125k
250k
500k



The CANopen protocol is not available

# 1020 FMD

## Profibus

<b>Address</b>	<input type="text" value="1"/>
<b>Format</b>	<input type="text" value="Floating Point"/>

### Address

Set the Profibus address for the device.

### Range

0...255

### Format

Set the format for the values sent over Profibus.

### Available options

Integer

Floating point

Select **Done** and click **End Quick setup**

<input type="button" value="End Quick setup"/>
--

This will finish the quick setup.


# 1020 FMD

## 5.2 Using the device


The menu structure in the device has no quick setup like the configuration software. The first use items can be set along with all other settings.

### Main Menu

From the main screen, press the Enter button for 2 seconds to enter the Main Menu.



Press 2 seconds



### Navigate through menu

Use the Up and Down button to navigate through the menus. Use the Enter button to enter a menu item. Use the Escape button to step back a level.



Up



Down



Open menu  
item



Back to  
previous level

# 1020 FMD

## Edit a value

```
20.000 kN
Min: -8388.608 kN
Max: 8388.607 kN
```

Use the arrow buttons to edit a value. Select the digit with the Left and Right button. Increase the value with the Up button. Decrease the value with the Down button. Use the Enter button to confirm the whole value. Use the Zero button to clear the whole value.



Select previous digit



Select next digit



Increase selected digit



Decrease selected digit



Confirm whole value



Clear whole value

## Edit a text

In case a text has to be edited, a keyboard appears on the screen.

```
Name
1020 FMD
1 2 3 4 5 6 7 8 9 0
q w e r t y u i o p
a s d f g h j k l OK
z x c v b n m ◀ ▶
```

Use the arrow buttons to navigate through the keyboard. Use the Enter button to select the character. Use the Zero button for backspace. Use the Peak-hold button to change the character set.



Left



Right



Up



Down



Select character



Backspace



# 1020 FMD




Change character set

## Indicator parameters


The indicator parameters from the quick setup can be set as follows:



# 1020 FMD



Enter the TAC as shown on the right bottom corner of the screen using the arrow buttons - apply with the Enter button



Here the Unit, Step size, Decimal point and Max load can be set







The predefined settings of step 2 in the quick setup are not available in the configuration menu of the device

# 1020 FMD




## Calibration

The calibration from the quick setup can be performed as follows:




Enter the CAL as shown on the right bottom corner of the screen using the arrow buttons - apply with the Enter button

# 1020 FMD




Make sure the load cell or force sensor is not loaded and is stable before pressing Enter




Make sure the load cell or force sensor is loaded with the reference weight and is stable before pressing Enter

# 1020 FMD



Enter the reference weight - apply with the Enter button



The device is now calibrated

# 1020 FMD

## 6 Full setup

The full setup is described with use of the configuration software. All settings are also available in the device menu. A full menu structure can be found in the attachment.

In the tree, select **PENKO 1020**. The properties of this tree node are shown in the right screen.

The screenshot displays a configuration interface. On the left, a tree view shows the hierarchy: PENKO > PENKO 1020 > 1.1.1 Name = > 1.1.2 Start Quick setup > 1.1.3 Enable Full setup > Live > System > Control > Access. The 'PENKO 1020' node is selected. On the right, a properties panel shows 'Class: PENKO.PENKO 1020' and 'Path: 1.1'. Below this, there is a 'Name' field and two buttons: 'Start Quick setup' and 'Enable Full setup'. The 'Enable Full setup' button is highlighted with a red rectangle.

The full settings are available under **Enable Full setup**


The screenshot shows a tree view with 'PENKO 1020' selected. The sub-items under 'PENKO 1020' are: 1.1.1 Name =, 1.1.2 Start Quick setup, 1.1.3 Enable Full setup, Live, System, System Setup, Control, and Access.



To confirm a setting press enter or click the Apply button

# 1020 FMD


## 6.1 Live



Live shows various live parameters of the device.

Node	Description
Indicator	Live indicator values and indicator status
Digital inputs	Live status of the 3 digital inputs (0 = OFF, 1 = ON)
Digital outputs	Live status of the 4 digital outputs (0 = OFF, 1 = ON)
Analog output	Live output percentage of the analog output
Counters	Live counter status of the 3 digital inputs


## 6.2 System



System shows the system information.

Node	Description
ID	Hardware ID of the device
Version	Version number of the firmware
Serial	Serial number of the device
Boot version	Version number of the boot loader

## 6.3 System Setup




System Setup contains the full device configuration.

### 6.3.1 Service

Service is for PENKO employees only.

### 6.3.2 Indicator

Indicator contains the indicator parameters and calibration.




## PARAMETERS

To enter the parameters, enter the shown TAC and confirm with Enter or the Apply button:



The parameters are now shown in the tree:



# 1020 FMD

## Properties

Properties contain the basic weigher parameters.

<b>Name</b>	<input type="text"/>
<b>Maxload</b>	<input type="text" value="20,000"/> kN
<b>Sample rate</b>	<input type="text" value="1600/s"/>

<b>Step</b>	<input type="text" value="STEP 1"/>
<b>Decimal point</b>	<input type="text" value="000.000"/>
<b>Unit</b>	<input type="text" value="kN"/>

### Name

Set a name to identify the device in a multiple device setup (optional).

### Maxload

Set the force the indicator will use as maximum. If the measured force is higher than the maximum load, the display will show =====

### Sample rate

Select the sample rate for measuring.

Available options
10/s
20/s
25/s
50/s
100/s
200/s
400/s
800/s
1600/s

# 1020 FMD

## Step

Select the step size. This setting defines the scaled parts of the force value. The display value will be rounded to the nearest value with a valid step size. Available options:

Available options
1
2
5
10
20
50
100
200

→ Example:

Measured value is 2005 kN.

Step size	Displayed value
1	2005
2	2006
5	2005
10	2010
20	2000
50	2000

## Decimal point

Select the position of the decimal point. This setting will be used everywhere the measured force is displayed or printed.

Available options
000000
00000.0
0000.00
000.000
00.0000
0.00000

# 1020 FMD

## Unit

Set the unit of measurement, for example kN or N. This will be shown everywhere the measured force is displayed or printed.

## Stable

The stable settings determine when the indicator accepts the current value as stable.

<b>Stable range</b>	<input type="text" value="0,002"/> kN
<b>Stable time</b>	<input type="text" value="1,00"/> s

### Stable range

Set the range the indicator has to be in for the set time to give a stable signal.

### Stable time

Set the time the weigher has to be within the range to give the stable signal.

With these values, the indicator has to be within the range of 0,002kN over the time of 1,00 second to indicate stable. When stable, the stable indication on the display will light up.

## Zero tracking

Zero tracking is able to tune the zero point back to zero when the scale becomes dirty.

<b>Tracking range</b>	<input type="text" value="0,100"/> kN
<b>Tracking step</b>	<input type="text" value="0,010"/> kN
<b>Tracking time</b>	<input type="text" value="1,00"/> s

### Tracking range

Set the maximum offset to tune back to zero.

### Tracking step

Set the step size that will be tuned every time the force is within the tracking range.

### Tracking time

Set the time that the force has to be within the tracking range to tune 1 step back to zero.

With these values, the indicator will step back 0,010kN towards zero every 1,00 second as soon as the measured force gets below 0,100kN.

# 1020 FMD

## Range/Interval

Set the indicator to change its step size when the measured force reaches a certain value.

<b>Range</b>	<input type="text" value="100"/> parts
<b>MaxStep</b>	STEP 50 ▼
<b>Mode</b>	MULTI-RANGE ▼

### Range

Set the number of divisions when the indicator has to display with the next step size. Auto ranging is disabled when range is set to 0.

### MaxStep

Select the biggest allowed step size.

Available options
Step 1
Step 2
Step 5
Step 10
Step 20
Step 50
Step 100
Step 200

### Mode

Select the mode. In multi-range mode the step size is reset when the indicator has been lower or equal to zero. In multi-interval mode the step size is reset when the value reached the previous range.

Available options
Multi-Range
Multi-Interval


→ Example:

With the shown values, the ranges are as follows:

# 1020 FMD

Range No.	Displayed range	Step size
Range: 1	0 - 100	1
Range: 2	100 - 200	2
Range: 3	200 - 500	5
Range: 4	500 - 1000	10
Range: 5	1000 - 2000	20
Range: 6	2000 - 5000+	50

The number of ranges depends on the selected max step size. In this case there are 6 possible ranges. The current range number is indicated in the display.



In multi-range mode, the range will only get back to range 1 when the indicator has been lower or equal to zero. In this case, when the value goes down, range 4 will remain active until the indicator reaches zero.

In multi-interval mode, the range number will follow the table above. In this case, when the value gets lower than 500, range 3 will become active, etc.

## Filter

Filters are used to filter vibrations present in an industrial environment.

Overall filter	0 dB
Filter type	Static
Cut Off	1,0 Hz
Moving Average	50 Hz

# 1020 FMD

## Overall filter

Select an overall filter. This will affect all indicator signals in the device. 0dB is no filtering. -48dB gives the strongest damping.

Available options
0 dB
-6 dB
-12 dB
-18 dB
-24 dB
-30 dB
-36 dB
-42 dB
-48 dB

To prevent a loss of information or accuracy, don't set the overall filter higher than 24dB. When no accuracy is needed, a higher filter setting is allowed to enable extreme filtering.

## Filter type

Select the type of filtering. This is a 2<sup>nd</sup> order filter. This filter affects all signals up to and including the cutoff frequency.

Available options	Description
None	No filter
Dynamic	Used when the signal is changing fast
Static	Used when the signal is changing slow

# 1020 FMD

## Cut Off

Select the cutoff frequency for the selected filter type.

Available options
1,0 Hz
1,4 Hz
2,5 Hz
5,0 Hz
10 Hz
20 Hz
40Hz

## Moving Average

Set the moving average frequency for the selected filter.

Range
0...50

## Display

The display filter will damp the indicator signal to the display to get a calm display view.

Rate	<input type="text" value="25/s"/>
Display Tracking:Filter range	<input type="text" value="0,000"/> kN
Display Tracking:Filter damping	<input type="text" value="0 dB"/>
Display Tracking:Zero suppress	<input type="text" value="0,000"/> kN

## Rate

Select the refreshment speed of the display.

Available options
1/s
2/s
3/s
5/s
10/s
25/s
50/s

# 1020 FMD

## Display Tracking: Filter range

Set the range where the filter is active.

## Display Tracking: Filter damping

Select the strength of the filter. 0dB is no filtering. -48dB gives the strongest damping.

Available options
0 dB
-6 dB
-12 dB
-18 dB
-24 dB
-30 dB
-36 dB
-42 dB
-48 dB

## Display Tracking: Zero suppress


Set the band within the indicator will show 0.

## CALIBRATION

To enter the calibration, enter the shown CAL and confirm with Enter or the Apply button:


<b>CAL</b>	<b>[0024]</b>
<b>Enter CAL</b>	<input type="text" value="24"/>

The parameters are now shown in the tree:



## Force calibration

Force calibration contains the calibration settings.



→ **Display** shows the current display values.

<b>Tracking</b>	<b>2,499 kN</b>
<b>Tracking x10</b>	<b>2,4989 kN</b>
<b>Signal</b>	<b>7,2070 mV</b>
<b>ADC</b>	<b>624890 ADC</b>

### Tracking

The current displayed tracking value.

### Tracking x 10

The current displayed tracking value with extra digit for more accuracy.

# 1020 FMD

## Signal

The current voltage, from the load cell or force sensor, in millivolts.

## ADC

The current ADC value.

→ **Points** show the stored calibration points.

Point 1	927717 ADC, 10,000 kN
Point 2	524006 ADC, 0,000 kN
Point 3	not used
Point 4	not used
Point 5	not used
Point 6	not used
Point 7	not used
Point 8	not used
Point 9	not used
Point 10	not used

Up to 10 calibration points can be stored to realize a multi-point calibration.

→ **Add/Replace point** is used to add a calibration point.

<b>Add/Replace point</b>	<input type="text" value="0,000"/> kN
--------------------------	---------------------------------------

When a point is added with a value that already exists, the existing point will be replaced. When a point is added with a new value, it will be stored as a new point.

→ **Delete point** is used to delete a calibration point.

<b>Delete point</b>	<input type="text" value="1"/>
---------------------	--------------------------------


Select the number of the calibration point (see Points) and confirm with Enter or the Apply button. The calibration point will be deleted.

# 1020 FMD

→ **Deadload** can be set to pull the whole measuring line back to zero. The zero point could be different because of some modification on the scale or dirt.

<b>Deadload</b>	<input type="text" value="0,000"/> kN
-----------------	---------------------------------------

Normally, the dead load is zero, but it's possible to change the line position if there's weight on the scale. To do so, edit the actual weigh value to the new known value.



## Transducers calibration

Transducer calibration is used for a theoretic calibration, using the datasheet of the load cell or force sensor. Up to 8 transducers can be set.

<input type="checkbox"/> Transducers calibration
<input checked="" type="checkbox"/> Transducer 1
<input checked="" type="checkbox"/> Transducer 2
<input checked="" type="checkbox"/> Transducer 3
<input checked="" type="checkbox"/> Transducer 4
<input checked="" type="checkbox"/> Transducer 5
<input checked="" type="checkbox"/> Transducer 6
<input checked="" type="checkbox"/> Transducer 7
<input checked="" type="checkbox"/> Transducer 8

For each load cell or force sensor the following data can be set.

<b>Output</b>	<input type="text" value="0,00000"/> mV/V
<b>Zero balance</b>	<input type="text" value="0,00000"/> mV/V
<b>Type</b>	<input type="text" value="None"/>
<b>Max load</b>	<input type="text" value="10,000"/> kN

# 1020 FMD

## Output

Set the output value as mentioned on the datasheet.

## Zero balance

Set the zero balance value as mentioned on the datasheet.

## Type

Set a name for the load cell or force sensor.

## Max load

Set the maximum load as mentioned on the datasheet.

## Input range

Input range is used to set the range for the connected load cell or force sensor.

Range	<input type="text" value="2 mV/V"/>
Offset	<input type="text" value="0"/>

## Range

Select the input range.

Available options	Description
1mV/V	
1,5 mV/V	
2 mV/V	Calibrated range*
2,5 mV/V	
3 mV/V	Calibrated range*


\* When using a theoretic calibration, note that these two ranges are officially calibrated

## Offset

Set an ADC value offset. This can be used when the indicator gets out of its ADC range.

## 6.3.3 Communication

Every available communication port has its own settings. The available ports depend on the option board.



### Ethernet

<b>MAC</b>	1E:30:6C:A2:45:5A
<b>Name</b>	<input type="text"/>
<b>Address</b>	<input type="text" value="10 . 1 . 2 . 69"/>
<b>Mask</b>	<input type="text" value="255 . 255 . 255 . 0"/>
<b>Gateway</b>	<input type="text" value="0 . 0 . 0 . 0"/>
<b>DHCP</b>	<input type="text" value="DISABLE"/>

#### MAC

This shows the MAC address of the device. This number cannot be changed.

#### Name

Domain Name System (DNS). A name can be given to the device to access the device in the Ethernet network by name instead of by IP address.

#### Address

Set the IP address of the device. Make sure the IP address is in the IP range of the network.

#### Mask

Set the subnet mask of the device.

#### Gateway

Set the gateway of the network the device is connected to.

#### DHCP

Dynamic Host Configuration Protocol (DHCP). When this function is enabled, the device gets an IP address, subnet mask and gateway address from the network it is connected to.

# 1020 FMD

## Ethernet BusLink

<b>Address</b>	<input type="text" value="0"/>
<b>Sub address</b>	<input type="text" value="0"/>

BusLink is a PENKO protocol to connect the device to a PENKO FLEX series device. The device parameters like indicator values and I/O status become available in the PENKO FLEX. A BusLink network can contain up to 40 PENKO devices (*8 addresses x 5 sub addresses*).

### Address

Set the BusLink address.

Available options
0 = off
1
2
3
4
5
6
7
8

### Sub address

Set the BusLink sub address.

Available options
0 = off
1
2
3
4
5

# 1020 FMD

## RS232 / RS422

<b>Protocol</b>	Printer ▼
<b>Address</b>	0
<b>Stopbits</b>	1
<b>Parity</b>	None ▼
<b>Baudrate</b>	9600 ▼
<b>Indicator</b>	0

The available options for RS232 and RS422 are the same and therefore described only once.

### Protocol

Select the protocol for the serial port.

#### Available options

None

Printer

ASCII

NPV Slave

MODBUS-RTU

MODBUS-ASCII

### Address

Set the address of the port for identification in the network.

#### Range

0...255

### Stopbits

Set the number of stop bits needed for the selected protocol.

#### Range

1...2

# 1020 FMD

## Parity

Set the parity needed for the selected protocol.

Available options
None
Odd
Even
Mark
Space

## Baudrate

Set the baud rate needed for the selected protocol.

Available options
1200
2400
4800
9600
19200
38400
57600
115200

## Indicator

This option is only active when ASCII is selected as protocol. The value of the selected indicator will be sent out over the communication port.

Range
1...30

# 1020 FMD

## CAN

<b>Protocol</b>	None
<b>Buslink Address</b>	0
<b>Buslink Subaddress</b>	0
<b>Baudrate</b>	250k

BusLink is a PENKO protocol to connect the device to a PENKO FLEX series device. The device parameters like indicator values and I/O status become available in the PENKO FLEX. A BusLink network can contain up to 40 PENKO devices (*8 addresses x 5 sub addresses*).

### Protocol

Enable or disable the BusLink protocol.

#### Available options

None
Buslink

### Buslink Address

Set the BusLink address.

#### Available options

1
2
3
4
5
6
7
8

# 1020 FMD

## Buslink Subaddress

Set the BusLink sub address.

Available options
1
2
3
4
5

## Baudrate

Set the baud rate equal to the baud rate of the connected PENKO FLEX.

Available options
100k
125k
250k
500k



The CANopen protocol is not available

# 1020 FMD

## Profibus

<b>Address</b>	<input type="text" value="1"/>
<b>Format</b>	<input type="text" value="Floating Point"/>

### Address

Set the Profibus address for the device.

### Range

0...255

### Format

Set the format for the values sent over Profibus.

### Available options

Integer

Floating point

# 1020 FMD

## 6.3.4 Digital inputs

The digital inputs can execute a function.

<b>Function 1</b>	HOLD
<b>Function 2</b>	NONE
<b>Function 3</b>	NONE

### Function

Select a function for the input.

Available options	Description
None	No function
Zero Set	Set indicator to zero
Zero Reset	Reset indicator from zero
Hold	Store current value as hold value
Peak Reset	Reset the peak hold value
Valley Reset	Reset the valley hold value
T.I.R.	Reset both peak and valley value
Keyboard Lock	Disable the device keyboard

## 6.3.5 Digital outputs

The digital outputs can respond to the value of an indicator.

- [-] Digital outputs
  - [+] Setpoint
  - [+] Action
  - [+] Function

### Setpoint

<b>Level 1</b>	0,000 kN
<b>Level 2</b>	1,000 kN
<b>Level 3</b>	2,000 kN
<b>Level 4</b>	3,000 kN

### Level

Set the level for each output when it has to turn on.



# 1020 FMD

## Action

Hysteresis 1	<input type="text" value="0,010"/> kN
Hysteresis 2	<input type="text" value="0,010"/> kN
Hysteresis 3	<input type="text" value="0,010"/> kN
Hysteresis 4	<input type="text" value="0,010"/> kN

## Hysteresis

Set the hysteresis for each output. The hysteresis can be positive or negative.



# 1020 FMD

## Function

Function 1	FAST TRACKING
Function 2	FAST TRACKING
Function 3	FAST TRACKING
Function 4	FAST TRACKING

## Function

Select the indicator the output has to react on.

Available options	Description
Fast Tracking	Unfiltered tracking value
Tracking	Filtered tracking value
Peak	Peak hold value - the highest measured value
Valley	Valley hold value - the lowest measured value
Hold	Hold value - stored with zero button in hold mode, or with hold input
T.I.R.	Total Indicated Readout value - the difference between the peak hold and valley hold value
Fast Tracking x10	Fast tracking with extra decimal for more accuracy
Tracking x10	Tracking with extra decimal for more accuracy
Peak x10	Peak with extra decimal for more accuracy
Valley x10	Valley with extra decimal for more accuracy
Hold x10	Hold with extra decimal for more accuracy
T.I.R. x10	T.I.R. with extra decimal for more accuracy
Sample	ADC sample value


→ Example:

Output	Setpoint	Action	Function	Description
1	1,000 kN	0,100 kN	Tracking	<i>Positive hysteresis - output will turn on at setpoint</i>
2	1,000 kN	-0,100 kN	Tracking	<i>Negative hysteresis - output will turn off at setpoint</i>

- Output **1** will turn **on** when the tracking value reaches **1,000 kN**
- It will turn **off** again when the tracking value drops below **0,900 kN** (1,000 - 0,100)
- Output **2** will turn **off** when the tracking value reaches **1,100 kN** (1,000 + 0,100).
- It will turn **on** again when the tracking value drops below **1,000 kN**

## 6.3.6 Analog output

The analog output is an option. The settings are only available when the DAC module is placed.



### Manual

<b>Manual output level</b>	<input type="text" value="0,00"/> %
	<input type="button" value="Manual control"/>
	<input type="button" value="Manual 0.00%"/>
	<input type="button" value="Manual 100.00%"/>
	<input type="button" value="Manual off"/>

#### Manual output level

Set the percentage for the output when manual control is enabled.

#### Manual control

Enable manual control of the output.

#### Manual 0.00%

Set the output to 0%

#### Manual 100.00%

Set the output to 100%

#### Manual off

Disable manual control of the output.

### Configuration

<b>Minimum Level</b>	<input type="text" value="0,000"/> kN
<b>Maximum Level</b>	<input type="text" value="10,000"/> kN
<b>Function</b>	<input type="text" value="PEAK"/> ▼
<b>Range</b>	<input type="text" value="4-20mA"/> ▼

# 1020 FMD

## Minimum level

Set the indicator value the analog output will set as 0.00% output.

## Maximum level

Set the indicator value the analog output will set as 100.00% output.

## Function

Select the indicator the output has to react on.

Available options	Description
Fast Tracking	Unfiltered tracking value
Tracking	Filtered tracking value
Peak	Peak hold value - the highest measured value
Valley	Valley hold value - the lowest measured value
Hold	Hold value - stored with zero button in hold mode, or with hold input
T.I.R.	Total Indicated Readout value - the difference between the peak hold and valley hold value
Fast Tracking x10	Fast tracking with extra decimal for more accuracy
Tracking x10	Tracking with extra decimal for more accuracy
Peak x10	Peak with extra decimal for more accuracy
Valley x10	Valley with extra decimal for more accuracy
Hold x10	Hold with extra decimal for more accuracy
T.I.R. x10	T.I.R. with extra decimal for more accuracy
Sample	ADC sample value

## Range

Select the range for the output.

Available options	Description
RAW	16 bit DAC value
0 - 20 mA	The minimum and maximum output of the analog output
0 - 24 mA	The minimum and maximum output of the analog output
4 - 20 mA	The minimum and maximum output of the analog output
4 - 24 mA	The minimum and maximum output of the analog output

# 1020 FMD


→ Example:

Minimum level	Maximum level	Function	Range
0,000 kN	10,000 kN	Tracking	4-20 mA

- If the tracking value is **0,000 kN**, the analog output will send out **4 mA** (0%)
- If the tracking value is **5,000 kN**, the analog output will send out **12 mA** (50%)
- If the tracking value is **10,000 kN**, the analog output will send out **20 mA** (100%)

## 6.3.7 Passwords

The access to some menu items can be protected with a password. This only applies when accessing the menu on the device itself. With the configuration software the menus can always be accessed.



### System Setup

Set a password for protecting the items within the system setup menu.


### Set Time/Date

Set a password for protecting the Set Clock menu item.

→ Example:



Enter a password for System Setup, for example 'abc'.

On the device, go to the System Setup menu:




Press 2 seconds


# 1020 FMD



Try to enter a menu item in the system setup menu




The password screen appears - enter the password to gain access to the menu item



The menu item is now available - when no actions are performed the access is blocked again after 60 seconds

## 6.3.8 Screen

In Screen all screen options can be set.



### Buttons

Up	T.I.R.
Down	Valley Hold
Left	None
Right	None
Enter	None
Zero	On
Track/Hold	On
Peak Hold	On
Esc/Print	On

The Zero, Track/Hold, Peak Hold and Esc/Print button can be enabled or disabled.

To the other buttons a function can be assigned. By default, T.I.R. is assigned to the Up button and Valley Hold is assigned to the Down button.

Available options	Description
None	No function
Zero Set	Set indicator to zero
Track/Hold	Toggle between tracking and hold display
Track	Show the tracking value on the display
Peak Hold	Show the peak hold value on the display
Valley Hold	Show the valley hold value on the display
T.I.R.	Show the T.I.R. value on the display
Hold	Show the hold value on the display
Set Levels	Open the setpoint screen
Print	Print, see printer settings menu




# 1020 FMD

## Led Bar

<b>Bar Style</b>	Bar
<b>Minimum</b>	0,000
<b>Lower Margin</b>	2,000
<b>Upper Margin</b>	8,000
<b>Maximum</b>	10,000
<b>Step</b>	1,000

### Bar Style

Select the style of the led bar. Bar Peak and Dot Peak show a peak value indication for a second when the value drops.

Available options	Description
Bar	
Dot	
Bar Peak	
Dot Peak	
Bar Reverse	
Dot Reverse	

### Minimum

Set the minimum value for the led bar.

### Lower Margin

Set a lower margin. This setting works together with the Upper Margin setting.

### Upper Margin

Set an upper margin. This setting works together with the Lower Margin setting.


The margin indication only works when both lower and upper margin are set.

# 1020 FMD


→ Example:

Bar Style	Minimum	Lower Margin	Upper Margin	Maximum	Step
Bar	0,000	2,000	8,000	10,000	1,000


Value below the margin is yellow:



Value within the margin is green:



Value above the margin is red:



## Maximum

Set the maximum value for the led bar.

## Step

Set the value of the step size between the minimum and maximum value.

## Screen Options

Decimal	<input type="text" value="."/>
Keybeep	<input type="text" value="No"/>
Language	<input type="text" value="English"/>
MenuTimer	<input type="text" value="0"/>
Indicator	<input type="text" value="DISPLAY"/>

## Decimal

Select the decimal character shown on the display

### Available options

, (comma)

. (point)



# 1020 FMD

## Keybeep

Enable or disable the key beep. When enabled, every key press is confirmed with a beep. When disabled, only entering the main menu (pressing enter for 2 seconds) gives a beep.

### Available options

No
Yes

## Language

Select the language for the device. This only applies to the device. The configuration software is always in English.

### Available options

English
German
French
Dutch

## MenuTimer

Set the time (in seconds) for auto escape menu. This only applies to the device. When a menu item is open and no action is performed during the set time, the menu jumps back one level. This is repeated until the device is back on the main screen.

If the value is set to 10 seconds or less, the auto escape function is disabled.

### Range

0...240
---------

# 1020 FMD

## Indicator

Select the indicator that is shown on the display. In case any other indicator than Display is selected, the buttons for showing the Tracking, Hold, T.I.R., Peak hold and Valley hold value are disabled.

Available options	Description
Display	Default display
Fast Tracking	Unfiltered tracking value
Tracking	Filtered tracking value
Peak	Peak hold value - the highest measured value
Valley	Valley hold value - the lowest measured value
Hold	Hold value - stored with zero button in hold mode, or with hold input
T.I.R.	Total Indicated Readout value - the difference between the peak hold and valley hold value
Display x10	Default display with extra decimal for more accuracy
Fast Tracking x10	Fast tracking with extra decimal for more accuracy
Tracking x10	Tracking with extra decimal for more accuracy
Peak x10	Peak with extra decimal for more accuracy
Valley x10	Valley with extra decimal for more accuracy
Hold x10	Hold with extra decimal for more accuracy
T.I.R. x10	T.I.R. with extra decimal for more accuracy
Sample	ADC sample value

## 6.3.9 Clock

The device date and time are used for printer tickets and for storing data in the alibi memory and event log. The device is equipped with a backup battery for the real time clock.

<b>Current Time</b>	<b>16:22:44</b>
<b>Current Date</b>	<b>08-08-2014</b>
<b>Set Time (HH:MM:SS)</b>	<input type="text" value="16:22:40"/>
<b>Set Date (DD:MM:YYYY)</b>	<input type="text" value="08-08-2014"/>

### Current Time

The current device time in HH:MM:SS format.

### Current Date

The current device date in DD-MM-YYYY format.



# 1020 FMD


## Set Time

Set the time in the indicated format to correct the device time.

## Set Date

Set the date in the indicated format to correct the device date.


An easy way to synchronize time and date is to use the Clock function in Pi Mach II.



Device Time:	Host Time:
<b>16:30:57</b>	<b>16:30:57</b>
Device Date:	Host Date:
<b>08-08-2014</b>	<b>08-08-2014</b>
<input type="button" value="Synchronize Date and Time"/>	

## 6.3.10 Printer

A printer can be connected to the Ethernet or the serial port. It's also possible to print to the build in alibi memory. Support for Zebra protocol printers is present.



## Settings

<b>Layout</b>	Ticket
<b>Columns</b>	40
<b>Rows</b>	24
<b>Margin</b>	2
<b>Newline</b>	CR+LF
<b>Port</b>	RS232 Port

# 1020 FMD

## Layout

Select the layout for printing. The **Ticket** layout is a predefined format. The **Line** layout prints every measurement on a new line. For both layouts a 24 and 40 columns format is present.

### 24 columns

### 40 columns

#### Ticket

```
Programmable header
-----
DATE      19-07-99
TIME      02:27.40
TICKET:   100

TRACK     0,855 kN
PEAK     1,509 kN
VALLEY    0,211 kN
HOLD     0,000 kN
T.I.R.   1,298 kN
-----
Programmable footer
```

```
Programmable header
-----
DATE      19-07-99
TIME      02:30.55
TICKET NUMBER: 101

TRACK     0,855 kN
PEAK     1,509 kN
VALLEY    0,211 kN
HOLD     0,000 kN
T.I.R.   1,298 kN
-----
Programmable footer
```

#### Line

```
Programmable header
-----
NR      Peak  Valley kN
119    1,509  0,211
120    1,509  0,211
121    1,509  0,211
```

```
Programmable header
-----
NR      Track   Peak   Valley
131    0,855 kN  1,509 kN  0,211 kN
132    0,855 kN  1,509 kN  0,211 kN
133    0,855 kN  1,509 kN  0,211 kN
```

Each print action has a number (ticket = ticket number, line = line number). When the device powers up the print counter is set to zero.

#### Available options

Ticket

Line

## Columns

24 and 40 columns printing is supported as shown in the layout examples.

#### Available options

0...39 = 24 columns

40...80 = 40 columns

# 1020 FMD

## Rows

For the ticket layout, the number of rows represents the empty lines after each ticket.

For the line layout, the number of rows represents the total number of rows for the header and the lines. When set to 1 for example, each printed line gets a header. When set to 10 for example, each 6 lines get a header (in case the header is 4 lines).

### Range

0...80

## Margin

Set the number of empty spaces before printing.

### Range

0...80

## Newline

Select the end of line sequence. When Zebra ZPL II is selected, a printer with this protocol can be used. The Zebra printer commands are automatically added to the printer ticket.

### Available options

CR

LF

CR+LF

CR+00

None

Zebra ZPL II

## Port

Select the communication port used for the printer.

Available options	Description
None	No printer
RS232 port	Set the printer parameters in System Setup - Communication - RS232
RS422 port	Set the printer parameters in System Setup - Communication - RS422
IP Number	Set the printer IP address in Ethernet printer - IP number
Alibi Memory	See chapter Alibi Memory and Event Log



# 1020 FMD

## Header

Header 1	<input type="text" value="Programmable header"/>
Header 2	<input type="text"/>
Header 3	<input type="text"/>
Header 4	<input type="text"/>

### Header 1...4

Optionally set a header for the printer ticket. Up to 4 lines can be programmed.

## Footer

Footer 1	<input type="text" value="Programmable footer"/>
Footer 2	<input type="text"/>
Footer 3	<input type="text"/>
Footer 4	<input type="text"/>

### Footer 1...4

Optionally set a footer for the printer ticket. Up to 4 lines can be programmed.

## Ethernet printer


IP number	<input type="text" value="0 . 0 . 0 . 0"/>
-----------	--

### IP number

In case the selected printer port in the settings menu is **IP Number**, enter the IP address of the printer.

## 6.3.11 Factory recall

A factory recall can be performed. Also the device parameters can be backed up and restored.



### Parameters to factory

Are you sure ?

Select yes to set all parameters to factory. The device reboots after this action.

### Backup

Are you sure ?

A backup of the device configuration can be made within the device. A password is required for the backup. Contact PENKO for this password. When using Pi Mach II manage to make a backup, enter this password in the service code field to enable the backup option.



### Restore parameters

Are you sure ?

This option only restores the non-certified parameters.

### Restore full

Are you sure ?

This option restores all parameters.

## 6.4 Control



Control has various functions to control the indicator.

Node	Description
Zero Set	Set the indicator value to zero
Zero Reset	Set the indicator value back to its original value
Hold Reset	Reset the stored hold value
Peak Reset	Reset the stored peak hold value
Valley Reset	Reset the stored valley hold value
TIR Reset	Reset the stored Total Indicated Readout value

## 6.5 Access



Access contains the Alibi Memory and Event Log.

Node	Description
Alibi	Browse, print or clear the Alibi Memory
Event Log	Browse of print the Event Log



Also see the Alibi Memory and Event Log chapter


## 7 Alibi Memory and Event Log

The Alibi and Event Log support the following features:

- Automatically store system events
- Create alibi records
- View, search and print alibi records and event logs

### 7.1 Alibi Memory

Alibi records are generated by a user action. To generate records, go to the Printer Settings menu and set Port to Alibi memory.



Every time the Print button is pressed, a new alibi record is created. To see the alibi record, go to the Access menu and select Alibi.



#### Number of entries

The total number of alibi records.

# 1020 FMD

## Entry Number

Enter the number of the desired record and conform with Enter or the Apply button. The record is shown.

## Record

The type of record. A record can be a **Header** or a **Data** record. A header records is the title of the record and shows a tag, date and time. A header has several data records that show the code, value and unit of the stored value.

## Tag/Code

Tag shows a tag the header record belongs to. By default this is "Alibi 001" and cannot be changed. Code shows the type of value stored in the data record.

## Date/Value

Date shows the date of the header record. Value shows the stored measurement of the data record.

## Time/Unit

Time shows the time of the header record. Unit shows the stored unit of the data record.

## UID

Every record has a Unique ID number, the UID.

## Print

This will print the total alibi memory to a connected printer. On the device it's possible to print only a part of the alibi memory. This is explained further on.

## Clear

This will clear the total alibi memory.

When the print button is pressed, 6 records are added to the alibi memory. This is 1 header record and 5 data records. Example:


Number	Record	Tag/Code	Date/Value	Time/Unit	UID
1	Header	Alibi 001	14-08-14	14:40:58	3298435072
2	Data	Force	0.783	kN	1755848705
3	Data	Peak	0.990	kN	2859737091
4	Data	Valley	0.129	kN	2346983429
5	Data	Hold	0.649	kN	0545136647
6	Data	T.I.R.	0.861	kN	2634031113

# 1020 FMD


Example of a printer layout of these records:

Device: 1020				
Serial Number 14080058				
Date : 14-08-14 Time : 15:02:53				
Alibi Memory				
Number	UID	Code	Date/Value	Time/Unit
1	3298435072	Alibi 001	14-08-14	14:40:58
2	1755848705	Force	0.783	kN
3	2859737091	Peak	0.990	kN
4	2346983429	Valley	0.129	kN
5	0545136647	Hold	0.649	kN
6	2634031113	T.I.R.	0.861	kN

The alibi records are also available on the device.



Press 2 seconds



Alibi memory	
all	
Entry	00006/00006
Code	T.I.R.
Date/Value	0.861
Time/Unit	kN
UID	2634031113

TAC:29 CAL:62

# 1020 FMD

Use the buttons for the following actions:



**Last**  
Jump to the last entry of the list.



**Filter**  
Filter the list on date or UID. Select All to undo the filtering.



**First/Clear**  
Jump to the first entry of the list.  
Press for 2 seconds to clear the alibi memory. A confirmation screen is shown first.



**Escape/Print**  
Leave the alibi memory.  
Press for 2 seconds to print all records to a connected printer. When a filter is active, the filtered range is printed.


**Previous**  
Select the previous record.



**Next**  
Select the next record.

## Clearing the alibi memory:

Press the Zero button for 2 seconds. The following screen is shown:



Press the Enter button to confirm or the Escape button to ignore.

# 1020 FMD

## Filtering the alibi memory:

Press the Enter button. The following screen is shown:

```
Select Log Range [3]
From Date
15-07-14
To Date
15-08-14
UID
0
▲▼◀▶ PH Tr/H +0+ ENTER ESC TAC:29
CAL:62
```

Use the “From Date” and “To Date” to set a date filter, or type in a UID to filter on 1 specific record. Leave the filter screen with the Escape button and the filter is applied.

```
Alibi memory [2]
15-07-14 .. 15-08-14 (6)
Entry 00006/00006
Code T.I.R.
Date/Value 0.861
Time/Unit kN
UID 2634031113
▲▼◀▶ PH Tr/H +0+ ENTER ESC TAC:29
CAL:62
```

When printing the alibi records, only the filtered range is printed.


To remove the filter, press the Enter button to open the filter screen. Select “All” and confirm with the Enter button.

```
Select Log Range [3]
To Date
15-08-14
UID
0
All
▲▼◀▶ PH Tr/H +0+ ENTER ESC TAC:29
CAL:62
```

## 7.2 Event Log

System events are generated automatically by the system. These events can be seen but cannot be erased. Erasing of the records can only be performed by PENKO. Events are created for logging software updates, calibration changes, parameter changes, clearing the alibi memory, etc.

To see the event log, go to the Access menu and select Event Log.



### Number of entries

The total number of event logs.

### Entry Number

Enter the number of the desired record and conform with Enter or the Apply button. The record is shown.

### Record

The type of record. An event log is always a **Header** record.

### Tag/Code

This shows the stored event, like Software Update, Set Clock, etc.

### Date/Value

This shows the date of the event.

### Time/Unit

This shows the time of the event.

### UID

Every record has a Unique ID number, the UID.

# 1020 FMD

## Print

This will print the total event log to a connected printer. On the device it's possible to print only a part of the event log. This is explained further on.


Examples:

Number	Record	Tag/Code	Date/Value	Time/Unit	UID
1	Header	SoftwareUpdate	31-0-14	09:11:28	3949592585
2	Header	TAC Changed	06-08-14	14:18:48	1045692434
3	Header	CAL Changed	14-08-14	14:40:22	4138074136


Example of a printer layout of these records:

```
Device: 1020
Serial Number 14080058
Date : 15-08-14   Time : 08:41:55
Event Log
Number UID      Code           Date/Value     Time/Unit
  1 0841613312 TAC Changed    30-06-14      11:43:48
  2 1371668481 TAC Changed    30-06-14      11:43:48
  3 1251344386 System Default 30-06-14      12:08:50
  4 1182662659 SoftwareUpdate 30-06-14      12:10:10
  5 4005953540 Alibi Cleared  30-06-14      13:50:20
```

The event records are also available on the device.



Press 2 seconds



# 1020 FMD

Event Log	
All	
Entry	00028/00028
Code	Set Clock
Date/Value	14-08-14
Time/Unit	14:40:46
UID	2158362651

▲ ▼ ◀ ▶ PH Tr/H +0+ ENTER ESC TAC:29 CAL:62

Use the buttons for the following actions:



**Last**  
Jump to the last entry of the list.



**Filter**  
Filter the list on date or UID. Select All to undo the filtering.



**First**  
Jump to the first entry of the list.



**Escape/Print**  
Leave the event log.  
Press for 2 seconds to print all records to a connected printer. When a filter is active, the filtered range is printed.



**Previous**  
Select the previous record.



**Next**  
Select the next record.

# 1020 FMD

## Filtering the event log:

Press the Enter button. The following screen is shown:

```
Select Log Range 3
From Date
15-07-14
To Date
15-08-14
UID
0
▲▼◀▶ PH Tr/H +0+ ENTER ESC TAC:29 CAL:62
```

Use the “From Date” and “To Date” to set a date filter, or type in a UID to filter on 1 specific record. Leave the filter screen with the Escape button and the filter is applied.

```
Event Log 2
15-07-14 .. 15-08-14 (19)
Entry      00019/00019
Code       Set Clock
Date/Value 14-08-14
Time/Unit  14:40:46
UID        2158362651
▲▼◀▶ PH Tr/H +0+ ENTER ESC TAC:29 CAL:62
```

When printing the event log, only the filtered range is printed.

To remove the filter, press the Enter button to open the filter screen. Select “All” and confirm with the Enter button.

```
Select Log Range 3
To Date
15-08-14
UID
0
All
▲▼◀▶ PH Tr/H +0+ ENTER ESC TAC:29 CAL:62
```

# 1020 FMD

## 8 Firmware update

Update the application firmware by Ethernet or USB connection.

### 8.1 Ethernet


Connect the 1020 FMD to the computer through Ethernet. Start PI Mach II. Set communication to Ethernet. Also see the Pi Mach II manual.



Start the Firmware Update Manager.




Click Open and select the PIP file.



Click Search for devices and select the device IP address for the 1020 FMD.




Use double click or the arrow button to move the device from the Source List to the Destination List and click OK.



# 1020 FMD

Now click Firmware Update to start the update.



The 1020 FMD will reboot automatically and the Firmware Update Manager will show Updated.


Device	Id-code	Softw Version	Status
<input checked="" type="checkbox"/> 10.1.2.68 - 0628	0628	0101	Updated

## 8.2 USB


Connect the 1020 FMD to the computer through USB. Start PI Mach II. Set communication to USB. Also see the Pi Mach II manual.




Start the Firmware Update Manager.



Click Open and select the PIP file.




Click Search for devices and select the device with source "0".




Use double click or the arrow button to move the device from the Source List to the Destination List and click OK.

# 1020 FMD



Now click Firmware Update to start the update.



The 1020 FMD will reboot automatically and the Firmware Update Manager will show Updated.

Device	Id-code	Softw Version	Status
<input checked="" type="checkbox"/> 0 -		0628 V:0101	Updated

## 9 Backup and restore

With the 1020 FMD it's possible to make a backup of the software as it's installed in the device. The software will be saved as an FDI file which stands for Flex Data Image. The Backup data assures that when the device fails, a replacement device can be programmed as a copy of the original device. In case of multiple devices which have to be configured similarly, one device can be programmed, and a backup of this device can be used to program the other device.

### 9.1 Backup

To back up the device, open Pi Mach II. Go to MENU → ENVIRONMENT → BACKUP DEVICE.



A save dialog is shown. Choose a destination and filename, and click SAVE. The image will be created and saved to this destination.

### 9.2 Restore

To restore the device, open Pi Mach II. Go to MENU → ENVIRONMENT → RESTORE DEVICE.



An open dialog is shown. Select the backup file, and click OPEN. The image will be programmed into the device, and the device will restart.

### 9.3 Progress

The progress of reading and writing is shown in a progress bar. The action can fail by a loss in communication between the PC and the controller. In that case the progress bar will be stuck somewhere between 0 and 100 %. In this case, check the communication and retry.

# 1020 FMD



## 10 Standard factory settings

Description	Display	Value	Your setting
<b>Properties</b>	Name	...	
	Unit label	kN	
	Step	1	
	Decimal point	0,000	
	Max Load	10,009 kN	
	Sample Rate	1600/s	
<b>Stable condition</b>	Range	0,002 kN	
	Time	1,00 s	
<b>Zero tracking</b>	Range	0,000 kN	
	Step	0,000 kN	
	Time	0,00 s	
<b>Range / Interval</b>	Range	0 Parts	
	Max Step	1	
	Mode	Multi Range	
<b>Filter - Overall</b>	Overall Filter	0 dB	
<b>Filter - Digital</b>	Digital Filter	Static App.	
	Cutoff Frequency	1,0 Hz	
	Frequency	50 Hz	
<b>Filter- Display</b>	Filter Range	0,000 kN	
	Display Filter	0 dB	
	Display Rate	25 updates/s	
	Disp.Suppress	0,000 kN	


## 11 Error codes

Error code	Description	Solution
<b>2001</b>	Parameter error	Invalid entry, choose valid value
<b>2005</b>	Input value is not valid	Invalid entry, choose value within range
<b>2101</b>	Weigher not stable	Wait for stable and try again
<b>2102</b>	Parameter exceeds maxload	Remove load / edit max load setting
<b>2103</b>	Parameter below zero	Check if scale is blocked
<b>2104</b>	Not in zero range	Remove load
<b>2105</b>	Arithmetic overflow occurred	Change calibration levels
<b>2106</b>	A/D reads all 1's	Check load cell connection
<b>2107</b>	A/D reads all 0's	Check load cell connection
<b>2108</b>	Gain ref. < zero ref.	Change calibration levels
<b>2109</b>	Gain > 0.99984741211	Change calibration levels
<b>2110</b>	Save error	Contact PENKO
<b>2111</b>	Flash ROM exhausted	Contact PENKO
<b>2112</b>	Error on header creation	Contact PENKO
<b>2113</b>	Error on date write	Contact PENKO
<b>2114</b>	Header validation failed	Contact PENKO
<b>2115</b>	De-active old data fail	Contact PENKO
<b>2116</b>	Load errors	Contact PENKO
<b>2117</b>	Item not found in store	Contact PENKO
<b>2118</b>	Error in stored data	Contact PENKO
<b>2119</b>	Bad calibration	Change calibration levels
<b>2120</b>	Action not enabled	-
<b>2121</b>	Multi-point not found	Add multi-point calibration
<b>2122</b>	Calibration table full	Remove calibration points
<b>2123</b>	Not allowed, tare active	Deactivate tare
<b>2124</b>	Action not allowed	-
<b>2125</b>	ADC no power	Check power supply
<b>CCCCC</b>	No proper calibration available	Check calibration setting
<b>UUUUUU</b>	Underflow	Check load cell Check platform construction
<b>OOOOOO</b>	Overflow	Check load cell Check platform construction
<b>=====</b>	Display overflow; Exceed maximum display value (max. load)	Reduce load on platform


## 12 Specifications

Type	Description
Wiring	With sense
Type of sense	Passive
Power supply	18-32 VDC; 7,5 W max.
Excitation voltage	5 VDC
Sensitivity	0,1 $\mu$ V/d
Selectable ranges	1 mV/V   1,5 mV/V   2 mV/V   2,5 mV/V   3 mV/V
Input voltage @3mV/V	-16 mV to 16 mV
A/D Conversion speed	1600/s
Max. load cell impedance	1200 $\Omega$
Min. Load cell impedance	43,75 $\Omega$
Max. no. of load cells 350 $\Omega$	8
Max. no. of load cells 1.000 $\Omega$	22
Max. number of d	10.000
Display resolution	100.000
Internal resolution	24 bits
Display steps	1,2,5,10,20,50,100,200
Display size	2,8 inch; 320 x 240 pixels
Digital inputs (3)	18 - 28 VDC, PNP or NPN
Digital outputs (4)	Max. 35V/0,5A, PNP or NPN
Analog output (optional)	0/4 - 20/24 mA, 10.000 d
Operating temperature	-10°C to +40°C
Storage temperature	-20°C to +70°C
Relative Humidity	Max. 85 % non-condensing
Protection class	IP45 or IP65 when built into a cabinet
Weight	700 g

# 1020 FMD



Top view



Side view

## Index

### A

Add/Replace .....	60
Address Ethernet .....	64
Address Ethernet BusLink .....	65
Address Profibus.....	70
Address RS232/422.....	66
Analog output connection .....	14

### B

Bar Style .....	79
Baudrate CAN .....	69
Baudrate RS232/422 .....	67
Buslink Address CAN.....	68
Buslink Subaddress CAN .....	69
Buttons functions .....	78

### C

CAL .....	24
CAN Bus connection.....	18
Clear alibi.....	90
Columns .....	84
Cut Off .....	57

### D

Date/Value alibi.....	90
Date/Value event .....	94
Deadload .....	61
Decimal character .....	80
Decimal point position.....	53
Delete point.....	60
DHCP .....	64
Digital inputs connection .....	15
Digital outputs connection .....	16
Display indications.....	22
Display Tracking: Filter damping ..	58
Display Tracking: Filter range .....	58
Display Tracking: Zero suppress ..	58
Display value .....	22

### E

Elevation .....	62
Entry Number alibi.....	90
Entry Number event .....	94

Ethernet connection .....	17
---------------------------	----

### F

Factory recall .....	87
Filter type .....	56
Filtering the alibi memory .....	93
Filtering the event log.....	97
Footer.....	86
Format Profibus.....	70
Function analog out.....	75
Function inputs.....	71
Function outputs .....	73

### G

Gateway.....	64
--------------	----

### H

Header .....	86
Hold .....	22
Hysteresis outputs.....	72

### I

Indicator on display .....	82
Indicator RS232/422 .....	67
IP number printer .....	86

### K

Keybeep .....	81
keypad .....	22

### L

Language .....	81
Latitude .....	62
Layout .....	84
Level outputs.....	71
Load cell connection .....	12
Lower Margin Led bar.....	79

### M

MAC .....	64
Manual 0.00%.....	74

Manual 100.00%.....	74
Manual control.....	74
Manual off .....	74
Manual output level .....	74
Margin .....	85
Mask subnet.....	64
Max load transducer .....	62
Maximum Led bar .....	80
Maximum level .....	75
Maxload.....	51
MaxStep (range/interval) .....	54
MenuTimer .....	81
Minimum Led bar .....	79
Minimum level .....	75
Mode (range/interval).....	55
Moving Average .....	57

### N

Name .....	51
Name Ethernet.....	64
Newline.....	85
Number of entries alibi.....	89
Number of entries event .....	94

### O

Offset input range .....	63
Operation mode.....	51
Output transducer.....	62
Overall filter .....	56

### P

Parity RS232/422.....	67
PDI Client software.....	26
Peak .....	22
Pi Mach II software.....	27
Port printer .....	85
Power supply connection .....	11
Print alibi.....	90
Print event .....	95
Profibus connection .....	19
Protocol CAN.....	68
Protocol RS232/422.....	66



## **R**

---

Range (range/interval).....	54
Range analog out.....	75
Range input range.....	63
Rate display.....	57
Record alibi.....	90
Record event.....	94
Rows.....	85
RS232/RS422 connection.....	20

## **S**

---

Sample rate.....	52
Service.....	50
Set Date.....	83
Set Time.....	83
Set Time/Date password.....	76
Stable range.....	53

Stable time.....	53
Step Led bar.....	80
Step size.....	52
Stopbits RS232/422.....	66
Sub address Ethernet BusLink.....	65
System Setup password.....	76

## **T**

---

T.I.R.....	22
TAC.....	24
Tag/Code alibi.....	90
Tag/Code event.....	94
Time/Unit alibi.....	90
Time/Unit event.....	94
Tracking.....	22
Tracking range.....	54
Tracking step.....	54
Tracking time.....	54
Type transducer.....	62

## **U**

---

UID alibi.....	90
UID event.....	94
Unit indication.....	53
Upper Margin Led bar.....	79
USB connection.....	13

## **V**

---


Valley.....	22
-------------	----

## **Z**


---

Zero balance transducer.....	62
------------------------------	----


## Appendix I - Menu structure



# 1020 FMD



# 1020 FMD



## Appendix II - Communication protocols

The following communication protocols are available:

Protocol	Available on port	Description
<b>Modbus TCP</b>	Ethernet (TCP)	Modbus protocol over Ethernet TCP used to connect to PLC.
<b>Modbus ASCII/RTU</b>	RS232/422	Modbus protocol over RS232 used to connect to PLC.
<b>Fins</b>	Ethernet (TCP)	Omron FINS protocol over Ethernet TCP used to connect to PLC.
<b>Ethernet/IP</b>	Ethernet (TCP)	Ethernet/IP protocol used to connect to PLC. The EDS file can be downloaded from the website.
<b>Profibus DP</b>	Profibus	Profibus protocol used to connect to PLC. The GSD file can be downloaded from the website.
<b>PENKO Printer</b>	Ethernet (TCP) RS232/422	PENKO printer protocol to connect ASCII/plain-text printers over Ethernet or serial connection. Zebra ZPL II protocol is supported.
<b>PENKO ASCII</b>	RS232/422 Ethernet (TCP)	PENKO protocol over Ethernet or serial connection.
<b>PENKO Buslink</b>	Ethernet (UDP) CAN	PENKO protocol over Ethernet or CAN connection used to connect PENKO devices to a PENKO FLEX controller.
<b>PENKO Web Interface</b>	Ethernet (TCP)	PENKO protocol over Ethernet to monitor and configure the device with a web browser.
<b>PENKO TP / PDI</b>	Ethernet (UDP) RS232/422 USB	PENKO protocol over Ethernet, serial and USB connection used for communication between the device and the configuration software.

Protocol descriptions and needed files can be downloaded from the PENKO website.



[www.penko.com](http://www.penko.com)



## About PENKO

Our design expertise include systems for manufacturing plants, bulk weighing, check weighing, force measuring and process control. For over 35 years, PENKO Engineering B.V. has been at the forefront of development and production of high-accuracy, high-speed weighing systems and our solutions continue to help cut costs, increase ROI and drive profits for some of the largest global brands, such as Cargill, Sara Lee, Heinz, Kraft Foods and Unilever to name but a few.

Whether you are looking for a simple stand-alone weighing system or a high-speed weighing and dosing controller for a complex automated production line, PENKO has a comprehensive range of standard solutions you can rely on.

## Certifications

PENKO sets high standards for its products and product performance which are tested, certified and approved by independent expert and government organizations to ensure they meet – and even – exceed metrology industry guidelines. A library of testing certificates is available for reference on:

[http://penko.com/nl/publications\\_certificates.html](http://penko.com/nl/publications_certificates.html)



## PENKO Professional Services

PENKO is committed to ensuring every system is installed, tested, programmed, commissioned and operational to client specifications. Our engineers, at our weighing center in Ede, Netherlands, as well as our distributors around the world, strive to solve most weighing-system issues within the same day. On a monthly basis PENKO offers free training classes to anyone interested in exploring modern, high-speed weighing instruments and solutions. A schedule of training sessions is found on: [www.penko.com/training](http://www.penko.com/training)

## PENKO Alliances

PENKO's worldwide network: Australia, Belgium, Brazil, China, Denmark, Germany, Egypt, Finland, France, India, Italy, Netherlands, Norway, Poland, Portugal, Slovakia, Spain, Syria, Turkey, United Kingdom, South Africa, Slovakia Sweden and Switzerland, Singapore. A complete overview you will find on: [www.penko.com/dealers](http://www.penko.com/dealers)

